



HELMET SIZING

JOE ROCKET

a smaller size.

CHEST

WAIST

SLEEVE

SLEEVE

LADIES JACKETS

INSEAM

SIZES

WAIST

SIZES

WAIST

INSEAM SHORT

INSEAM REG.

INSEAM REG.

INSEAM TALL

MENS ATOMIC PANT

34-36

26-28

32

32

307/8

MENS BLASTER 2.0 PANT

31-32

32

N/A

S

31-32

32-33

32

34

М

32-33

34-35

32

34

34-35

PROPER HELMET FITMENT

AWARNING Never buy a used helmet or borrow someone else's helmet. Over time the protective foam in helmets will adjust to the contours of a user's head. A used or borrowed helmet may not offer as much protection as a new helmet.

AWARNING Wearing the wrong size helmet can increase your risk of serious injury or death in an accident. A helmet that is too large for your head may be dislodged or knocked off in an accident. To select the right size helmet for your head, follow these instructions: 1. Measure your head. Wrap a tape measure around your head about one

inch (2.5 cm) above your eyebrows. 2. Use the sizing chart to select the helmet size that corresponds most closely

try on the larger helmet first and then the smaller size. Click here to see the sizing chart. 3. Try on the helmet by grasping both chin straps to pull the helmet complete-

to your head measurement. If your head size falls between two helmet sizes,

ly onto your head, ensuring that the top of your head is in contact with the top of the helmet interior. **4.** Check for a proper fit. To make sure your helmet is the right size, check

that: A. The helmet inner lining fits snugly around your head. B. The top pad presses firmly on your head. C. The cheek pads contact your cheeks. D. There is no space around your brow under the inner lining. Test this by trying to insert your fingers. If the helmet does not fit snugly, try on

5. Check your field of vision when trying on a helmet. Some helmets may obstruct or block your vision when looking left, right, up, or down.

ADULT JOE ROCKET

6. Test the helmet fit by placing your hands on

Always make sure you can see well enough to safely operate your motorcycle.



big, try a size smaller. You should feel the helmet move the skin on your head and face as you try to move the helmet. * Modular Helmets were designed to be used in the closed chin bar position,

each side of the helmet. While holding your head as motionless as possible, try rotating your helmet

from left to right then up and down. If you can feel the helmet padding sliding on your head, it is too

thus be sure all helmet "fitting" is done while chin bar is in the closed and locked position. 7. Fasten the retention system (chin strap) as tight as possible under your jaw

without causing pain. There must be no slack in the strap, and the strap must be tight up against your jaw. Click to view the helmet retention system.



Put your hands on the back of the helmet and try to push the helmet off by rotating it forward.

8. Test the retention system (chin strap)

Put your hands on the front of the helmet above your forehead (or on the chin guard) and try to

push the helmet off by rotating backward. If helmet comes off, try another size or another model or brand.

XL

54-56

42-45

36.5

36

36

32 3/8

38

28-29

38-39

32

s

28-29

38-39

35

38

34 3/4

3XL

41-44

30

32

33 1/2

26-27

36-37

32

LADIES ALTER EGO PANT

XS

26-27

36-37

35

58-60

45-49

36.5

36.5

אוח 2 אוח 1/ וצב

323/4

40

30-31

40-41

L

32-33

42-43

35

40

35

4XL

45-48

N/A

32

33 1/2

32-33

42-43

32

XL

34-35

44-45

35

2XL

61-63

49-53

37

36.5

33 1/8

42

34-35

44-45

32

36-37

46-48

35

42 35 1/2

5XL

49-52

N/A

32

33 1/2

Repeat steps 3 through 8 until you find a helmet that fits your head snugly and securely.

SIZE	CENTIMETER	HAT SIZE	INCHES
XS	53 - 54	6 ^{5/8} - 6 ^{3/4}	20 ^{7/8} - 21 ^{1/4}
SM	55 - 56	6 ^{7/8} - 7	21 ^{5/8} - 22
MD	57 - 58	7 1/8 - 7 1/4	22 ^{1/2} - 22 ^{7/8}
LG	59 - 60	7 3/8 - 7 1/2	23 ^{1/4} - 23 ^{5/8}
XL	61 - 62	7 5/8 - 7 3/4	24 - 24 ^{3/8}
2XL	63 - 64	7 7/8 - 8	24 ^{3/4} - 25 ^{1/4}

MENS LEATHER RACE SUIT

MEN'S SIZING

SIZE	38	40	42	44	46	48	50	52	54	56	
CHEST	37-38	39-40	41-42	43-44	45-46	47-48	49-50	51-52	53-54	55-56	
WAIST	29-30	30-32	30-34	32-36	34-38	36-40	38-42	40-44	42-46	44-48	
SLEEVE	31	31	32	33	34	35	35	35	35	35	
INSEAM	31	32	32	32	33	33	34	34	35	35	
AP. WEIGHT	125-140	135-150	150-175	160-185	170-195	180-205	190-215	200-225	210-235	220-245	
AP. HEIGHT	AP. HEIGHT 5'4"-5'10" 5'6"-5'10" 5'7"-6'1" 5'9"-6'1" 5'9"-6'2"										
* Inseam measurements for suits run from crotch to above the ankle bone.											
MENS SUF	RVIVOR SI	TIL									

SIZE S CHEST 34-36 38-40 40-42

40-42

32-34

33

33

XS S M I

CHEST		34-36		38-40	40	-42	42-44		46-48
WAIST		26-28		29-31	32	-34	34-36		36-39
SLEEVE		32		32	3	3	34		35
INSEAM REG		34		34	3	4	34		34
INSEAM SHOP	RΤ	N/A		30.5	30	0.5	30.5		30.5
* Short sizes are 3.5" shorter on the inseam.									
MENS JACKETS ALPHA									
SIZES	XS	S	М	L	XL	2XL	3XL	4XL	5XL

46-48

36-39

35

50-52

39-42

36

35

42-44

34-36

34

34

* For tall size jackets, add 2" to the sleeve length and 3" to the torso length. **NUMERICAL** SIZES 38 40 42 44 46 48 50 52 54 56 CHEST 40 42 44 46 48 54 56 50 52 WAIST 29 32 34 38 40 42 44 46 48 50

35

WOMEN'S SIZING

31 1/4

32

35-38

32

34

38-41

32

34

XL

35-38

33

For tall size jackets, add 2" to the sleeve length and 3" to the torso length.

38-40

29-31

32

SIZES	Λ0	"	141	_	\\	EXE/ I DIVA	L DIVA		
BUST	31	33-34	35-36	37-39	40-42	42-44	45-48		
WAIST	24-25	26-27	28-29	30-31	32-34	34-36	37-39		
HIP	35-36	37-38	39-40	41-42	43-44	44-45	46-49		
MENS SPEEDMASTER 5.0 PANT									
SIZES	30	32	34	36	38	40	42		
\A/AIGT	20	20	24	26	20	40	40		

32

36

WAIST

INSEAM

SIZES

WAIST

INSEAM *

36

34 1/4

2XL

38-41

30

32

HIP

HIP

31 5/8

WAIST	;	30	;	32	;	34	36		38	40			42
INSEAM	30	7/8	31	1/4	31	5/8	32		32 3/8	32 3/	4	3	3 1/8
MENS ALTER EGO 2.0 PANT LADIES CLEO PANT													
SIZES	S	М	L	XL	2XL	3XL	SIZES	xs	S	М	L		XL

41-44

32

34

2XL

38-41

INSEAM	34	34	34		34		34	
LADIES B	ALLISTI	C 7.0 PA	TNA					
SIZES	XS	S	N	/	L		XL	2XL
WAIST	26-27	28-29	30	-31	32-3	33	34-35	36-37
HIP	36-37	38-39	40	-41	42-4	13	44-45	46-48
INSEAM *	35	35	3	5	35	5	35	35

MENS PRO STREET PANT										
SIZES	30		32		34					
WAIST	30		32		34					
INSEAM REG.	33		33 1/2		33 3,	/4				
MENS BALLISITC 7.0 PANT										
SIZES	S		M		L	>	(L			
WAIST	30-31		32-33	3	34-35	35	5-38			

*Height adjusta	ble hem. Adjusts	to 31", 33" or 35"		
36	38	40	4	2

М

30-31

40-41

INSEAM Short	N/A	32	32	32	32	32	N/A	N/A
INSEAM Reg	34	34	34	34	34	34	34	34
INSEAM Tall	N/A	36	36	36	36	36	N/A	N/A
* For tall sizes, add 2" to the length and for short sizes subtract 2" to the length.								
MENS PHOENIX 2.0 PANT								
SIZES	s	М	L	XL	2XL	ЗХL	4XL	5XL
WAIST	30-31	32-33	34-35	35-38	38-41	41-44	45-48	49-52

30

32

rer snort sizes subtract 2 to the length.									
MENS ROCKE	T DENIM JEAN	IS							
SIZES	30	32	34	36	38	40			
WAIST	30	32	34	36	38	40			
INSEAM SHORT	31 1/2	31 1/2	31 1/2	31 1/2	31 1/2	31 1/2			

30

32

33 1/2 33 1/2 33 1/2 33 1/2 INSEAM REG.

30

32

INSTRUCTIONS	MEASURING		
	INSTRUCTIONS	_	

your armpits and around your back. Be sure arms are in a resting position on your sides. 2. Waist - Measure the smallest point of your waist. 3. Sleeve - Measure from the middle of the back of your neck,

go over your shoulder, and over your elbow ending at your

N/A

32

the crotch to the top of the ankle. For all other pants mesure the inseam from the crotch down to the foot

5. Hips - Measure around the fullest part of your body at the top of your leg.

NOTE: For best results, we suggest that measurements not be done over clothing.



