EE Installation Instructions













WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer. 5 2 08



- If the linkage guard is to be installed on a skid plate that is already installed on a bike, remove the skid plate from the bike.
- Using the 8 x 20 flat head skid plate mounting bolts that came with your skid plate, mount the supplied drill template/insert installation tool to the top side of the skid plate as shown in (Fig 1)
- Use the supplied 25/64" drill bit to start a hole in the skid plate at the location of the largest diameter hole of the drill template/installation tool as shown in (Fig 2)
- 4 Unbolt the drill template/installation tool and turn it 180 degrees and bolt it down again.
- 5 Repeat step 3 to start a hole in the other side of the skid plate.
- 6 Unbolt and remove the drill template/installation tool.
- 7 Finish drilling the 2 insert holes in the skidplate.
- 8 Insert one of the supplied threaded inserts in one of the holes you just drilled.
 Insert from the bottom of the skid plate. (Fig 3)
- 9 Using your Skid Plates rear mounting bolts, tighten down the installation tool snug against the Skid Plate.
- 10 Insert the supplied 6x30mm insert installation bolt and washer through the smaller insert installation hole in the drill template/insert installation tool (Fig 4) and thread it into the threaded insert until the head of the installation bolt is slightly snug against the drill template/insert installation tool. (Fig 5)

- Now tighten the insert installation bolt until the end of the bolt is flush with the end of the insert. (Fig 6)
- 12 Remove the insert installation bolt and installation tool.
- Insert the other supplied threaded insert into the other drilled hole you drilled. Insert from the bottom of the skid plate.
- Repeat steps 9, 10 and 11 to seat the other supplied threaded insert
- Mount the skid plate on the bike by following the skid plate installation instructions.
- 16 Mount the linkage guard to the skid plate using the supplied 6 x 20mm hex head bolts and the supplied dished washers.



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Installation

Part# 31-017