



Asterisk



SIZING

Circumference Measurement



To ensure a proper fit, circumference measurements should be taken directly on the skin with the leg straightened, using a soft tape measure. (If a soft tape measure is not available, a piece of string or yarn may be used, then measured against a hard tape measure.) Locate the middle of the kneecap and measure around the leg.



Circumference Measurement Sizing Chart

(in)	10-1/4" ~ 13-7/8"	13" ~ 14-1/8"	14-1/4" ~ 15-3/4"	15-7/8" ~ 16-7/8"	17" ~ 18"
(cm)	26.04 ~ 32.7	33.02 ~ 35.7	36 ~ 39.5	40.2 ~ 42.7	43 ~ 45.6
	JR MICRO CELL	SML	MED	LRG	XLG



Asterisk